

Подключение термостата Ecotherm Wi-Fi к мобильному приложению

1.




[Android App](#)

[Iphone App](#)

[App store input lin rongfeng](#)


2. Enter the local WiFi name and WiFi password



Note: Wifi name can't include the sign "-" and "_"


3. Press and hold on the "⏻" button,

then press the "⌚" together




4. Enter to the advanced setting,

then press the "🔄" 9 times until appears the "FAC"




5. When appear the "FAC" button, then



press the "▲" button and up-regulation to "10" or "32"






7. Press the power key, then the thermostat will be shutdown




Press the power key, the thermostat will be shutdown

8. Press and hold on the “” button, then press the “”, the wifi icon beging flashing WiFi fast flashing show




Press and hold on the “” button, then press the “” button
The WiFi icon beging flashing


9. Enter the WiFi name and password, then start connection



10. If the thermostat and the mobile phone connection is success, the WiFi icon will stop flashing



11. Finished configure, get to the search list and click the thermostat equipment



12.

